

qui ckqui de

- 1) Download the sataboot.iso
- 2) Burn iso image onto a cd.
- 3) Using a PC, install the SATA Controller and boot from the cd.
- 4) Once in DOS, please follow these instruction:

type: x: (press enter) x=cd rom drive letter - ex: d: (enter)
type: cd 3124 (press enter) *or repl ace 3124 with your chipset on your sata controller such as 3114 or 3132
type: above1m (press enter)

For Rai d Bi os:

type: updf325 r6409.bi n (press enter) * r = raid b = base

For Base Bi os:

type: updf325 b6409.bi n (press enter) * r = raid b = base

reboot the computer and make sure your controller said "SATARAID or SATALINK"

SATARAID = Rai d Bi os

SATALINK = Base Bi os